



GCP-20 Series

Genset Control Package

Mains & Generator Protection & Control

APPLICATIONS

The GCP-20 Series genset control is designed to provide total control for stand-alone and multiple unit applications in isolated or mains parallel operation.

There are three GCP-20 Series Packages available for various genset applications. The GCP-20 is designed for stand-by gensets. Open or closed transition power transfers including logic for two circuit breakers. The GCP-21 is designed for continuous parallel operation and has control logic for one circuit breaker. The GCP-22 has control logic for two circuit breakers that enable automatic power transfers like open transition, closed transition and softloading.

Load management features include automatic base/peak shaving, import/export control and emergency power/back up power generation.

DESCRIPTION

Features (all versions)

- True RMS voltage (generator/busbar/mains)
- True RMS current (generator/mains)
- Start/stop logic for Diesel/Gas engines
- Engine pre-glow or purge control
- Battery voltage monitoring
- Speed control with overspeed monitoring
- kWh/oper.hours/start/maintenance counter
- Configurable trip/control set points
- Configurable delays for each protection
- Speed input (magnetic/switching pickup, MPU)
- 14 configurable discrete alarm inputs
- 4 configurable/programmable relays
- Two-line LC display
- Push-buttons for direct control
- Multi level password protection

Controller (all versions)

- Speed/frequency/voltage
- Isolated operation

DESCRIPTION (continued)

Protection (all versions) ANSI

Mains

- Over-/undervoltage (59/27)
- Over-/underfrequency (81O/U)
- Phase/vector shift (78)

Generator

- Over-/undervoltage (59/27)
- Over-/underfrequency (81O/U)
- Overload/reverse power (32/32R)
- Unbalanced load (46)
- Time-overcurrent (50)

GCP-20 (unique features)

Synchronizer for GCB and MCB

- AMF automatic mains failure
- Open transition (break-before-make)
- Closed transition (make-before-break)

GCP-21/-22 (unique features)

Synchronizer for GCB

- Real power/power fact. cosphi control
- Mains parallel operation
- Mains import/export power control
- Reduced power monitoring (32F)
- Load dependent start/stop
- Load/var sharing (up to 8 units)

GCP-22 (unique features)

Synchronizer for GCB and MCB

- AMF automatic mains failure
- Open transition (break-before-make)
- Closed transition (make-before-break)
- Softloading

Special (Version dependent)

- 2 configurable analog outputs (0/4 to 20 mA)
- Generator real power setpoint via 0/4 to 20 mA
- Discrete raise/lower for n/f/V/P/Q
- Analog raise/lower for n/f/V/P/Q
- 3 conf. analog alarm inp. (0/4 to 20 mA, VDO)
- CAN bus communication

- Complete engine, generator, and mains protection and controller into one unit
- AMF auto start/stop
- True RMS sensing
- Synchronization for one/two breakers
- Load management-automatic base load/peak shaving, import/export power control
- Automatic start/stop sequencing
- Load/var sharing
- Counters for kWh, engine starts, operating hours, maintenance call
- Freely configurable discrete and analog alarm inputs
- Freely configurable relay and analog outputs
- PC and front panel configurable
- CAN bus communication
- CE marked
- UL/cUL Listed

FEATURES OVERVIEW

GCP-20 Series Genset Control	GCP-20					GCP-21				GCP-22				
	Package	T2	LS	B	X	LSX	LS	LSB	LSR	LSX	LS	LSB	LSR	LSX
Control														
Breaker control logic	2	2	2	2	2	1	1	1	1	2	2	2	2	
Synchronization	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
Isolated single-unit operation	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
AMF (auto mains failure operation)	✓	✓	✓	✓	✓					✓	✓	✓	✓	
Stand-by operation	✓	✓	✓	✓	✓					✓	✓	✓	✓	
CHP (combined head & power) operation						✓	✓	✓	✓	✓	✓	✓	✓	
Peak load operation (auto start/stop)						✓	✓	✓	✓	✓	✓	✓	✓	
Mains parallel operation						✓	✓	✓	✓	✓	✓	✓	✓	
Open transition (break-before-make)	✓	✓	✓	✓	✓					✓	✓	✓	✓	
Closed transition (make-before-break)	✓	✓	✓	✓	✓					✓	✓	✓	✓	
Softloading						✓#1	✓#1	✓#1	✓#1	✓	✓	✓	✓	
Accessories														
Start/stop logic for Diesel/Gas engines	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
kWh counter	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
Operating hours/start/maintenance counter	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
Configuration via PC #2	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
Protection														
Generator: voltage/frequency	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
Mains: volt./freq./phase shift						✓	✓	✓	✓	✓	✓	✓	✓	
Generator: overload	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
Generator: reverse power	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
Generator: reduced power						✓	✓	✓	✓	✓	✓	✓	✓	
Generator: unbalanced load	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
Generator: time-overcurrent (TOC)	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
Controller														
Discrete raise/lower: n/f	✓	✓				✓				✓				
Discrete raise/lower: U	✓	✓			✓	✓		✓		✓		✓		
Discrete raise/lower: P						✓				✓				
Discrete raise/lower: Q						✓		✓		✓		✓		
Analog raise/lower: n/f (+/-3 Vdc)			✓	✓	✓		✓	✓	✓		✓	✓	✓	
Analog raise/lower: U (+/-5 Vdc)			✓	✓			✓		✓		✓		✓	
Analog raise/lower: P (+/-3 Vdc)							✓	✓	✓		✓	✓	✓	
Analog raise/lower: Q (+/-5 Vdc)							✓		✓		✓		✓	
Mains import/export power (cur. meas.)						✓	✓	✓	✓	✓	✓	✓	✓	
Load-dependent start/stop						✓	✓	✓	✓	✓	✓	✓	✓	
Real power setpoint value: 0/4 to 20 mA									✓				✓	
Load/var sharing		✓			✓	✓	✓	✓	✓	✓	✓	✓	✓	
I/Os														
Speed input (magnetic/switching Pickup)	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
Discrete alarm inputs (configurable)	14	14	14	14	14	14	14	14	14	14	14	14	14	
Relay outputs (configurable)	4	4	4	4	4	4	4	4	4	4	4	4	4	
Analog inputs (configurable)	2 #3			4 #4	4 #4			4 #4	3 #5			4 #4	3 #5	
Analog outp. 0/4 to 20 mA (configurable)									2				2	
CAN bus communication #6		✓		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
Listings/Approvals														
CE marked	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
UL/cUL listed	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
Product number P/N														
120 Vac, ..1/5 A		8440-1581	5448-878	5448-877	8440-1584	8440-1586	8440-1541	8440-1346	8440-1587	8440-1590	8440-1103	8440-1052	8440-1591	
400 Vac, ..1/5 A	8440-1038	5448-918	8440-1582	8440-1583	5448-917	5448-916	8440-1014	5448-915	8440-1013	5448-914	8440-1012	5448-913	8440-1011	

#1 In isolated parallel operation with min. 2 gensets in parallel

#2 Cable incl. software necessary (DPC)

#3 [T1] & [T2] = 0/4 to 20 mA

#4 [T1]= VDO 0 to 5/10 bar; 0 to 180 Ohm; [T2] = VDO 40 to 120°C; 0 to 380 Ohm; [T3] & [T4] = 0/4 to 20 mA; freely scaleable

#5 [T1]= VDO 0 to 5/10 bar; 0 to 180 Ohm; [T2] = VDO 40 to 120°C; 0 to 380 Ohm; [T3] = 0/4 to 20 mA; freely scaleable

#6 Remote monitoring, control, configuration (GW 4 could be used for several interfaces)

International
 Woodward
 PO Box 1519
 Fort Collins CO, USA
 80522-1519
 1000 East Drake Road
 Fort Collins CO 80525
 Ph: +1 (970) 482-5811
 Fax: +1 (970) 498-3058

Europe
 Woodward Governor Company
 Leonhard-Reglerbau GmbH
 Handwerkstrasse 29
 70565 Stuttgart, Germany
 Ph: +49 (0) 711-789 540
 Fax: +49 (0) 711-789 54-100

Distributors & Service
 Woodward has an international network of distributors and service facilities. For your nearest representative, call the Fort Collins plant or see the Worldwide Directory on our website.

Corporate Headquarters
 Rockford IL, USA
 Ph: +1 (815) 877-7441

www.woodward.com
 /smart-power

For more information contact:

Subject to technical modifications.

This document is distributed for informational purposes only. It is not to be construed as creating or becoming part of any Woodward Governor Company contractual or warranty obligation unless expressly stated in a written sales contract.


We appreciate your comments about the content of our publications. Please send comments including the document number below to stgt-doc@woodward.com

© Woodward Governor Company

All Rights Reserved

03243B - 05/1/S

WIRING DIAGRAM (GCP-20 and GCP-21 upon request)



GCP-22 (Version 3.xxxx)

The socket for the PC configuration is situated on the side of the unit. This is where the DPC has to be plugged in.